

ASSEMBLY INSTRUCTIONS:

- 1) Place 2 bolts (#4) through square holes in caster base as shown. Make sure the square shoulder on bolt stays fit in square hole on caster.
- 2) Place caster onto plastic body of creeper (#1). Make sure that the bolts go through both holes provided in the creeper body.

 3) Slide sleeve (#7) onto male portion of bolt (#4) that is sticking up through the body of the creeper. Sleeve should recess into body of creeper.
- 4) Secure with nut (#5).
- 5) Repeat procedure for each caster.

ORDERING PART#	ITEM#	PART DESCRIPTION
PRT81050-01	1	MAIN CREEPER BODY
ATD81004	2	CASTER
PRT81050-03	3	HEADREST
PRT81050-H	4	HARDWARE PACKAGE (includes 12 nuts, 12 sleeves and 12 nuts)
	5	
	6	