











and then fill the pump oil to the oil-level.

·To store the pump when not in use for long periods of time, cover the oil cap and exhaust cap and store it in a dry place.

·**Repair of pump should only be done by experienced repair facilities.**

## **9. Technical Specifications**

Model: ATD-3425

Model Power Supply: 110V 60HZ

Free Air Displacement: 5 CFM

Number of Stages: 1 Stage

Ultimate Vacuum: 180 Micron

Rotating Speed: 1720 r/Min

Motor: 1/3 HP

Weight: 14 KGS

